

8103 Program modification for Ultra Stick

1. Go to Function List
2. Go to D/Flap T.
3. Activate Pot 6 (flap)
4. Go to a Program Mix (any mix but 1 or 2) 3 or 4 would be best
5. Set up Flap-to-Flap mix (flap switch should be on LAND pos.)
6. Turn flap pot to full negative value.
7. Select "Offset" in the mix and press Clear/Store button (the offset value should be between -171 and -222)
8. Go to D/Flap T. and set Pot 6 to INH
9. Return to your Flap-to-Flap mix
10. With flap switch in top (ELEV) position, adjust the upper rate value until the flaps are level.